

## Zinger Stun Guns™ - The Rabbit Zinger™, (TRZ001)

### Terms of Sale: Read Carefully!

Here are our terms of sale. By ordering, you agree to the following.

You must be at least 18 years of age to purchase and/or use our products and services, and you agree not to allow anyone under the age of 18, and without proper guidance from you, use our products.

You must keep our products away from children and properly store in a safe place when not in use.

All users must be of sound body and mind.

### YOUR OWN RISK:

Sal Pizzurro/ MHS, LLC shall not be held liable for any damage occurring from purchasing, receiving, and/or using our products and services. The End user shall not hold us responsible for any loss due to the use or handling of any of our products or services. While every step is taken to ensure usage is smooth and without problems, like all tools and equipment success is dependent on various factors, including the user's physical ability, skill level, maturity and other factors. Practice may be needed to achieve successful results and safe operation.

The buyer takes full responsibility to make sure that the end user is fully aware of proper use and the risks involved in the use of these products. We recommend that you save a copy of this document. If you lend, gift, or sell any of our products, to anyone, give them a copy of this document.

### -Warnings, proper use and handling-

#### The Rabbit Zinger™

##### Steps for proper Use:

1. Put rabbit on table or solid horizontal surface.
2. Hold the "Handle Grip" with one hand and grasp the Bolt "Finger Pull" with the other hand.
3. Pull the "Bolt" back until the "Trigger Pin" drops into the "Pin Catch" on the "Bolt"
4. The gun is now "cocked/ loaded and ready to fire" and you may now release the finger pull.
5. Keep your fingers off of the trigger until you intend to fire.
6. Secure the rabbit by placing your non dominant hand on the rabbits shoulder area, or gently hold the rabbit in place by the ears. **(The rabbit needs to be properly restrained during this process)**  
*(Hint: The rabbit should put its head down when you attempt to stroke its head.)*
7. Keep all body parts at least 3 inches away from muzzle of gun and never put any body parts under the rabbit or gun.
8. Position the barrel of the gun on top of the rabbits head at the proper location and apply slight pressure (+ or - 5 pounds) **(Connect an imaginary line from each ear to the opposite eye. Where the lines intersect is the proper location. If you are not sure, move closer to the ears, not the eyes) see fig. 1.** Failure to hit the correct location may cause the rabbit to be injured, and not properly stunned, in which case, the rabbit must be put down immediately using an alternate method **(IE: The Rabbit Wringer™ TRW001)**
9. Apply moderate pressure with the barrel against the rabbit's head at the correct location, being sure that the rabbit's chin is touching the work table.
10. After practice, you may not need to have the head down on the table. Find the technique that works best for you.
11. Pull the trigger to fire the gun. Maintain steady pressure (approx. 5 lbs) through the discharging of the gun. (Due to minor recoil, adequate pressure needs to be applied so that the full force of the bolt is concentrated on target).
12. Do not pull the gun away as you pull the trigger.
13. The Rabbit should be hung immediately and bled out by slitting the throat.
14. We highly recommend that you practice at least 5 times on a piece of soft wood (at least a 2" x 4" x 12" piece of lumber). Mark X's for your targets and be sure your hitting the X's before using the gun on a live animal.

Fig. 1



**Warning! Read Carefully!**

- Always wear safety goggles (eye protection) and (hand Protection) leather gloves or similar work or mechanic's gloves when in use. All bystanders must also wear eye protection.
- Never point the Zinger gun at anyone.
- Always treat the gun as if it's loaded.
- Never point the Zinger gun at any part of your body. Keep hands and fingers away from the front of the gun barrel when cocked/ loaded.
- Keep fingers off and away from trigger until you are ready to fire.
- Never dry fire the gun (this means firing into thin air or at nothing).
- Always have at least one shock washer installed and in good condition on the back of the bolt when in use, or damage to gun may occur. Make sure to change out the shock washers if they become damaged or worn or damage to gun may occur.
- Never test fire the gun on anything other than a pre-killed animal or a soft piece of lumber. Test fire only on a stable horizontal surface.
- Inspect **Power Tubes**™ prior to each use and replace if worn, weakened or damaged.
- **Power Tubes**™ will become weakened over time or due to excessive use and they must be replaced with new power **Tubes** to ensure a clean humane kill.
- Store **Power Tubes**™ for up to two years in a cool dry location and away from direct sunlight.
- Use the **Zinger**™ **Stun Gun** & **Power Tubes**™ only in areas heated to at least 50 °F. Operating the Zinger Stun Gun in extreme cold conditions will cause the gun to lose power and not be effective.
- Use only Genuine **Zinger Gun Power Tubes**™, parts, and accessories.

**Failure to follow these instructions may cause serious injury or even death  
The Purchaser assumes full responsibility, and releases Sal Pizzurro/ MHS, LLC from any liability**

By ordering our products, you agree with these terms.